

Repairs to Damaged Surfaces

Clean the damaged area with a solvent moistened tissue to ensure there are no oil or grease residues on the surface. Clean across the area with a spatula to remove any small chips or fragments.

Select the correct colour and squeeze out a liberal amount onto the edge of the ColorFill spatula. Position the spatula behind the area to be repaired and press firmly down on the surface pulling the spatula toward you filling the area with ColorFill.



TIPS

ColorFill®

**250+ colours
to suit all popular
laminite finishes**

Finishing Off

TIPS

To clean off overfill use a solvent moistened tissue around the repair taking care not to clean out the filled area.

Do not ever mix solvent with ColorFill and only wipe around the damaged area, not in it or the material will be dislodged in this early stage before setting.

Using a spatula scrape off the overfill from around the damage and draw the spatula across the damage to ensure that all overfill has been removed.

It is important to keep the spatula blade perfectly clean to ensure a smooth finish.

ColorFill is a one component product and may shrink slightly during drying. Depending on the result a second or third coat may be necessary to build up the depth. Clean off the overfill between each application.

For final clean up allow 24 hours to fully harden and clean the area with household washing up liquid and warm water.